

INON

Safety Precautions

- Before using your flashlight, please ensure that you have read and understood the safety precautions described below and separate 「user manual」 / 「Measures to Prevent Accidental Flooding」. Please keep these documents handy for easy reference.
- The safety precautions are intended to instruct you in the safe and correct operation of the strobe to prevent injuries or damage to yourself, other persons and equipment.
- The symbols and their significance are described below.



DANGER

Failure to observe the precautions indicated by this symbol may lead to high possibility of serious injury or death.



WARNING

Failure to observe the precautions indicated by this symbol may lead to possibility of serious injury or death.



CAUTION

Failure to observe the precautions indicated by this symbol may have the possibility of resulting in possibility of injury or property damage.



WARNING

DO NOT turn on the flashlight in front of person's eye (particularly an infant).

The flashlight may cause irreparable injury to the eyes or cause temporary visual impairment.

DO NOT use FULL mode on land (except for brief function check less than 5 minutes in total)

Always use heat-safe gloves when using the light on land to avoid burns including low temperature burns where you do not feel so hot.

DO NOT use the flashlight in a place where it may be exposed to flammable or explosive gas.

Otherwise fire ignition or explosion may result.

Turn OFF the flashlight when not in use. (Never leave the product being ON)

Remove batteries immediately after exhaustion.

Batteries could produce flammable gas causing the flashlight to explode. Storing the flashlight with batteries for extended periods of time could cause batteries to leak, overheat or explode which may result in fire, injury or damage to other property.

When turn OFF the light, lock the switch at OFF position.

Remove batteries when not in use.

Unexpected activation of the light by vibration etc. could cause fire or injury.

Storing the light with batteries for extended periods of time may cause batteries to leak, overheat or explode which may result in fire, injury or damage to other property.



WARNING

Never leave or carry battery loaded battery cartridge as it is.

Make sure to store in insulated container like a ziplock to avoid short-circuit which could generate flammable gas from batteries and possibly cause accidental explosion or battery to explode, or lead to fire/injury/property damage due to battery leakage or generated heat.

Never attempt to modify the flashlight or disassemble the light head to avoid malfunction, damage or flooding, which could lead to injury.

Prevent water from entering the flashlight to avoid malfunction, damage or flooding, which could lead to injury.

Always check O-rings, batteries and flashlight operation before using to avoid flooding, malfunction and unexpected deactivation of the product due to battery exhaustion, which could lead to an accident.

Stop operating and turn off the flashlight immediately if any water is observed inside flashlight or flashlight operates improperly.

Flammable gas may build up and cause explosion of the product, which may result in serious injury. Remove batteries being careful to avoid electrical shocks or burns. Contact your local dealer for repair.

DO NOT use flammable solvent containing alcohol, benzene or thinners, oil and fat containing/chemical material like organic solvent, rust inhibitor, lubricant, polish, or alkaline detergent to clean the flashlight.

The use of these substances may lead to fire, explosion or damage to the flashlight.

Keep the flashlight out of reach of children.

Their inability to read and understand warnings may lead to serious injury. They may swallow parts of the strobe or batteries. See a doctor immediately if a child swallow parts or batteries.



CAUTION

DO NOT apply strong vibration or shock to the flashlight by dropping or hitting it against something.

Damage to the flashlight could cause malfunction or flooding possibly leading to injury or fire. Strong vibration/shock could deform batteries or damage battery case causing battery to leak or to generate heat resulting in fire or injury.

DO NOT “jump” into the water with the flashlight or other photographic equipment to avoid injury which may be caused by malfunction, flooding or unexpected movement of equipment.

DO NOT leave/store the flashlight in a place subject to strong sunlight or high temperatures, such as a beach, the deck of a boat, dashboard or trunk/boot of a vehicle.

Otherwise damage to the flashlight may result in injury, fire or malfunction.

Partially unscrew the Light Head or remove it for flying or traveling to other areas with lower air pressure than sea level (traveling across mountains for example) to avoid damage to waterproof integrity which may result in flooding or injury.



DANGER

DO NOT use batteries other than batteries specified in user manual.

[Compatible batteries]

- Panasonic AA “eneloop” rechargeable battery (BK-3MCC) [recommended] ,
- Panasonic AA “eneloop pro” rechargeable battery (BK-3HCC, BK-3HCD) [recommended] , and
- (“eneloop” type) “new generation” NiMH battery with same performance
- “Conventional” NiMH battery (1.2V) other than above [good quality]
- AA Alkaline (1.2V)

DO NOT use any battery which you observe irregularity including leakage, deformation, discoloration or damage on battery jacket etc.

DO NOT throw a battery in a fire or heat it. Never attempt to disassemble or short-circuit a battery.

DO NOT immerse battery in water or allow it to get wet.

DO NOT mix old and new batteries, recharged and discharged batteries or batteries of different capacities, types, brand or manufacturer.

DO NOT attempt to recharge non-rechargeable batteries.

Be sure to recharge rechargeable batteries with specified battery charger. Follow battery and battery charger instruction manual.

DO NOT load batteries with the +/- battery terminal reversed

Follow any other instructions indicated in the battery/battery charger user manual.

Dispose batteries in accordance with all applicable federal, state and local regulations.

If the battery should leak • • •

- Keep away from fire to avoid ignition/explosion.
- Should inner liquid contact skin or eyes, or get into mouth, immediately wash with a lot of fresh water and seek medical advice.

INON LF1100h-EWf Light Head

Thank you for purchasing INON product.

This product is a service part for INON LF1100h-EWf and optional light head.

This unit is not usable as standalone and has to be properly assembled with compatible LF series LED flashlight battery box in exchange with pre-installed light head. Be sure to read this manual and relevant document to ensure you proper operation of the product.

Package contents :	<ul style="list-style-type: none"> LF1100h-EWf Light Head ×1 <div style="border-left: 1px solid black; border-right: 1px solid black; border-bottom: 1px solid black; padding: 5px; display: inline-block;"> LF1100h-EWf Light Head Body 2 Click Selector Ring LF Unit (Selector Ring LF 2 Click Fixing Ring LF) Protector LF-EW </div> This instruction manual ×1 LF1100h-EWf 「User Manual」 ×1 LF1100h-EWf 「Maintenance of Selector Ring LF Unit」 ×1 LF1100h-EWf 「Safety Precautions」 ×1
---------------------------	--

Other standard packaged accessory of the 「LF1100h-EWf」(「Dome Red Filter LF-EW」/「Light Shade LF-EW」/「INON Grease」etc.) are not included and optionally available.

Compatible LF series LED Flashlight (compatible "battery box unit" to attach this unit) :

- INON LF1000-S (LF1000-S Battery Box Unit)
- INON LF1100-W (LF1100-W Battery Box Unit)
- INON LF800-N (LF800-N Battery Box Unit)
- INON LF1300-EWf (LF1300-EWf Battery Box Unit)
- INON LF650h-N (LF650h-N Battery Box Unit)
- INON LF1100h-EWf (LF1100h-EWf Battery Box Unit)

This unit is for 3 x AA operated LF-1000S, LF1100-W, LF800-N, LF1300-EWf, LF650h-N and LF1100h-EWf but not usable for LE series LED flashlights or LF series flashlight (LF1400-S, LF2700-W, LF3100-EW, LF2400h-EW) which runs by 6 x AA batteries.

- Handling Precautions:**
- Before shipping, this product has been tested its water-proof property by manufacture with special jig tool. However you have to take full responsibility on assembling with a battery box unit to ensure water-proof property as whole LED flashlight since assembly with a battery box unit is done by a customer and INON INC. are unable to check how you assemble nor conduct pressure test of the assembled unit. Please be sure to read relative user manual/instruction manual carefully and follow them to ensure you with proper assembling. Before using assembled unit, we would recommend to conduct leak test as necessary. **INON INC. cannot take any responsibility for any problem resulting from assembly of this unit. Please contact purchasing dealer before assembling if you are not fully confident in installing this unit on your battery box unit.**
 - Before assembling, be sure to read though the LF1100h-EWf 「**Safety Precautions**」 **comes with this product** and follow warnings/cautions described there.
 - Refer to the LF1100h-EWf "User Manual", "Maintenance of Selector Ring LF Unit" **comes with this product** and "**Measures to Prevent Accidental Flooding**" **comes with your LF series LED flashlight** to see how to assemble, use and conduct maintenance.
 - **DO NOT** disassemble this unit to prevent malfunction/flooding.

INON INC. 2-18-9 Dai, Kamakura, Kanagawa 2470061 Japan
 E-mail support@inon.co.jp / Fax.+81(0)467-48-2178
 URL http://www.inon.jp/

As of May 2019

INON

INON LF1100h-EWf

Thank you for purchasing INON product.


The INON LF1100h-EWf is a watertight LED flashlight equipped with high-intensity power LED producing powerful 1100 lumen intensity with wide 100° coverage underwater supporting “shutter-linked Auto OFF” function in addition to two power setting in its compact body.

Before using, please read through this user manual and separate leaflets [Safety precautions]/[Measures to Prevent Accidental Flooding] to ensure proper operation of the product. FULL mode is not usable on land except functional check not exceeding 5 minutes operation time in total. Refer to [Handling precaution] section in this manual for detail.

Features

- Usable as serious lighting device for photography/videography with 100° wide coverage underwater, color temperature 6,500K to reproduce natural color in addition to a diving light carrying 120m depth rating thanks to its durable corrosion-resistant aluminum alloy and double O-ring construction for moving parts.
- Color temperature is approx. 6500K making it easier to reproduce natural color when mixing with ambient light or strobe light comparing to warmer color temperature torch.
- Newly equipped “Shutter Linked AUTO-OFF” function supports automatic shut-off for only about 0.2 sec in synch with either built-in flash or external strobe triggered by shutter-release not to expose LED light on an image. This function is manually deactivated for video light use not to have intermittent lighting created by other diver's strobe.
- Simple yet durable and user-friendly rotary switch assures you reliable ON/OFF and power setting operation. Operated by easily obtainable 3 x AA batteries. Compatible batteries including “eneloop” / “eneloop pro” etc. support approx. 45 minutes (FULL) or approx. 220 minutes/3hrs 40min (LOW) continuous operation (※) at minimal running cost.
※Average time to get half brightness comparing to initial performance when using “eneloop pro” batteries [Model code : BK-3HCD].
- Two bundled accessories come with this product “Light Shade LF-EW” can block a part of LED light not let to shine an attachment lens directly to suppress flare/ghost or suspended particles between a lens and subject to prevent backscatters. The “Dome Red Filter LF-EW” only changes color not to stimulate shy marine lives.
- Wide varieties of optional accessories are available including “Light Holder” products to attach this product on your camera/video system.
- Light Head is interchangeable with other compatible model for another application.

- Package contents :**
- LF1100h-EWf ① x1
 - LF1100h-EWf Light Head x1
 - LF1100h-EWf Light Head Body Protector LF-EW
 - 2 Click Selector Ring LF Unit
 - Selector Ring LF ⑥
 - 2 Click Fixing Ring LF ⑦
 - LF1100h-EWf Battery Box Unit x1
 - 3xAA Battery Box LF
 - Switch
 - Lock Ring
 - 3xAA Battery Cartridge LF x1 (preinstalled in the battery box)
 - Hand Strap ② (preinstalled on ①) x1
 - INON Grease ③ x1
 - Dome Red Filter LF-EW ④ x1
 - Light Shade LF-EW ⑤ x1
 - This user manual x1
 - Safety Precautions x1
 - Measures to Prevent Accidental Flooding x1
 - Maintenance on Battery Terminals/Contacts x1
 - Maintenance of Selector Ring LF Unit x 1
 - User manual of filters/Light Shade x1



Preparation : **Prepare compatible batteries**

Following 3 types are compatible with this product (*1). Prepare 『three』 batteries (same type/model) from same battery manufacture.

- 1) **Panasonic AA “eneloop” rechargeable battery (BK-3MCC) [recommended] , Panasonic AA “eneloop pro” rechargeable battery (BK-3HCD) [recommended] and equivalent (“eneloop” type) “new generation” NiMH battery (*2)**
- 2) **AA “conventional” NiMH rechargeable battery other than above (1.2V) [good quality] (*3)**
- 3) **AA Alkaline battery (1.5V)**

*1 Other batteries are not usable such as AA Manganese battery, AA Oxyride battery or AA Lithium (1.5V) battery etc. Make sure to follow precautions of handling batteries described in separate [Safety Precautions].

*2 Including “new generation” NiMH batteries (“eneloop” type) carrying less self-discharging and heat generating characteristic comparing to “conventional” or “high-capacity” NiMH.

*3 Some “conventional” or “high-capacity” NiMH rechargeable batteries have significant self-discharge and heat-generating characteristic resulting difficulty to keep their performance during usage. We recommend using recommended batteries.

(continued)

Turn OFF, lock, remove LF1100h-EWf Light Head

Turn OFF the LF1100h-EWf by rotating the “switch” counterclockwise until it has been stopped. Pull up the Lock Ring (①) and rotate it counterclockwise(②) to match its ▽ mark with “LOCK” position on “3xAA Battery Box LF” (③). Then screw in the switch (④) until it has been stopped to lock the switch position at OFF.



Next, with holding the “3xAA Battery Box LF(⑤)” firmly, slowly turn the “LF1100h-EWf Light Head Body” counterclockwise by holding its black rubber ring(⑥) to separate whole of the “LF1100h-EWf Light Head” from the battery box unit.

To keep waterproof property, make sure slowly turn the “switch”/“LF1100h-EWf Light Head” to prevent O-ring from being damaged/twisted.




It is recommended **not to remove the “Protector LF-EW” from the “LF1100h-EWf Light Head Body”** to protect the “LF1100h-EWf Light Head Body” unless installing packaged filter or conducting maintenance after use. Refer to respective user manual of filter/Light Shade or 「Maintenance」 section of this manual for detail of handling precautions when installing/removing “Protector LF-EW”.

Load Batteries in 3xAA Battery Cartridge LF

Take out “3xAA Battery Cartridge LF” from “3xAA Battery Box LF”. Conduct maintenance of “3xAA Battery Cartridge LF” in reference to 「Terminals/Contacts Maintenance」 section of this user manual.

Then install batteries in the “3xAA Battery Cartridge LF” with correct orientation as shown on stickers inside of the “3xAA Battery Cartridge LF” [Negative terminals must touch spring contacts]



Also make sure to follow any handling precautions on battery mentioned in separate 「**Safety Precautions**」.

Once batteries are loaded in “3xAA Battery Cartridge LF”, put it immediately in “3xAA Battery Box LF” with the LF1100h-EWf being OFF or in an insulated container such as ziplock.

NEVER leave or carry battery loaded “3xAA Battery Cartridge LF” as its battery contacts being exposed.


Doing so may have short circuit causing batteries to produce heat/explode/leak battery fluid resulting in fire/injury/property damage

Install 3xAA Battery Cartridge LF after Checking O-ring etc.

Check conditions of O-rings etc. and conduct leak test if necessary to ensure waterproof property in accordance with separate paper 「**Measures to Prevent Accidental Flooding**」.

Next, conduct maintenance in reference to 「Terminals/Contacts Maintenance」 section of this user manual, then install the 3xAA Battery Cartridge LF with correct orientation as shown in image right and indicated on a sticker inside of the “3xAA Battery Box LF”.

[Positive terminal [Red] facing up]

**Attach the LF1100h-EWf Light Head**

Apply thin film of INON grease on the thread part of the “3xAA Battery Box LF” to prevent 「salt build-up」or 「electric corrosion」causing anchoring between the “LF1100h-EWf Light Head” and the “3xAA Battery Box LF”. **DO NOT** apply grease on electrical contacts to avoid bad connection.

Make sure the LF1100h-EWf is OFF once again at this stage, then **hold the black rubber ring of the “LF1100h-EWf Light Head Body” to slowly screw whole of the “LF1100h-EWf Light Head” onto the “3xAA Battery Box LF” as shown in image on the next page until it has been stopped** with holding the “3xAA Battery Box LF” firmly.



No grease on contact points with “LF1100h-EWf Light Head”

Grease the thread part of the “3xAA Battery Box LF”

Check/maintain “3xAA Battery Box LF” O-rings



Never hold the “Protector LF-EW” when screwing the LF1100h-EWf Light Head to prevent damage on the “Protector LF-EW”, “2 Click Selector Ring LF Unit” or “LF1100h-EWf Light Head Body”.

To keep waterproof property, make sure slowly turn the “switch”/“LF1100h-EWf Light Head” to prevent O-ring from being damaged/twisted.

(continued)

Attach an accessory as necessary

Attach 「Light Shade LF-EW」 or 「Dome Red Filter LF-EW」 as necessary. Refer to respective user manual for detail.

The 「Dome Red Filter LF-EW」 is designed for underwater use and *not* usable on land.

Operation

- : **Unlock the switch** *Reverse procedure of previous "Turn OFF, lock, remove LF1100h-EWf Light Head" section
Rotate the switch counterclockwise until lightly stopped, turn the Lock Ring clockwise to match ▽ mark with △ mark on the "3xAA Battery Box LF", then hold it down to unlock the switch.

Always lock the switch at OFF position except for activating the light.


NEVER leave or carry the product with being the switch unlocked.

Doing so may cause unexpected operation of the product resulting in fire/injury/property damage.

ON/OFF , Selecting Power

To turn OFF the LF1100h-EWf, slowly turn the switch counterclockwise until it has been lightly stopped. To Turn ON, slowly turn the switch clockwise to get LOW mode first and rotate further until it has been lightly stopped for FULL mode.

Make sure to turn all the way to the either end to turn ON(FULL)/OFF the LF1100h-EWf. *When using LOW mode, make sure to turn 1/4 rotation further after activating the light.* Any position except OFF/LOW/FULL may possibly cause unstable operation like unexpected ON/OFF or flicking of the LF1100h-EWf.




To keep waterproof property, make sure slowly turn the "switch"/"LF1100h-EWf Light Head" to prevent O-ring from being damaged/twisted.

ON/OFF Shutter-Linked AUTO-OFF function

When using "Shutter-Linked AUTO-OFF" function to shoot a still image, set the white triangle on the Selector Ring LF of the light head to activate the function.

Once enough strobe light reaches to the "sensor", AUTO-OFF function is activated to cease lighting in synch with the strobe light then back on after about 0.2 seconds. If the sensor detects another strobe light during AUTO-OFF stage, it further adds another 0.2 seconds shut off duration from the strobe light detection.



If Shutter-Linked AUTO-OFF function doesn't work well, try to change aiming of this product or move close to the subject to increase incident light coming in the "sensor".

This Shutter-Linked AUTO-OFF can be activated by other diver's strobe light or reflecting sunlight from the surface. Turn the "Selector Ring LF" to set the white triangle to "OFF" position *not* using the "Shutter-Linked AUTO-OFF" function to use this product to avoid those unexpected activation or use this product as a video light etc.

Whenever turning the "Selector Ring LF", make sure to gently grab the ring only with two fingers as in the right image to switch between ON and OFF position.



DO NOT grab other than the "Selector Ring LF", grab firmly/grab only fingertips, override ON/OFF position etc. could lead to accidental loosening of the "LF1100h-EWf Light Head" and succeeding flooding, damage on the "Protector LF-EW", "2 Click Selector Ring LF Unit" and/or "LF1100h-EWf Light Head".

Change/Remove Batteries

The LF1100h-EWf must be dry to change/remove batteries in accordance with previous 「Preparation」 section. If even a small amount of water contacts inside "LF1100h-EWf Light Head" or contacts/terminals for short period of time, there will be corrosion of contact points or cause short circuit, and the LF1100h-EWf may become inoperable.


Changing/removing batteries is not recommended if the LF1100h-EWf is not completely dry. However if you have to change/remove battery before drying the LF1100h-EWf, follow procedure below;

- 1) Thoroughly wash the LF1100h-EWf in fresh water and wipe off water drops with an air blower etc. in reference to "Maintenance" section.
- 2) Hold the LF1100h-EWf with facing up so that no water droplets can enter inside the "LF1100h-EWf Light Head" or drip on contacts/terminals.
- 3) Slowly unscrew the "LF1100h-EWf Light Head" with facing it up to prevent water from getting in to take out batteries.

Maintenance**Rinse and Dry Completely**

After dive soak the LF1100h-EWf in fresh water for several hours (water temperature should be 0°C ~ +30°C/32°F ~ 86°F) **without any protector/filter/accessory** to remove salt etc. Slowly turn the "switch", "Selector Ring LF" to remove trapped salt etc. but **DO NOT** turn the "LF1100h-EWf Light Head" underwater. Then **wipe off water droplets by an air blower etc.** and dry the product completely in shaded and well ventilated area (it may take several days completely dry).

When removing the Protector/filter/Light Shade, **make sure to hold the black rubber ring on the "LF1100h-EWf Light Head Body" instead holding the "3xAA Battery Box LF" or "2 Click Selector Ring LF Unit" to prevent "LF1100h-EWf Light Head Body" from loosening resulting in accidental flooding and or damage on "2 Click Selector Ring LF Unit" or "LF1100h-EWf Light Head Body"**

**Remove Batteries and Check/Clean/Grease Thread Part/O-rings etc.**

Make sure that the LF1100h-EWf is completely dry, and "Protector LF-EW" is attached. Remove batteries in reverse procedure to loading batteries explained in [Preparation] section. Check/clean/grease O-rings, O-ring grooves, O-ring contact surfaces and thread parts of the "LF1100h-EWf Light Head"/"3xAA Battery Box LF" in reference to separate leaflet **Measures to Prevent Accidental Flooding**.

DO NOT screw protector/filter/Light Shade too tight.

Doing so could cause jamming leading to accidental flooding as the "LF1100h-EWf Light Head Body" could be loosen when removing accessory and/or damage on protector/filter/Light Shade or "2 Click Selector Ring LF Unit". "LF1100h-EWf Light Head Body".

If the "Selector Ring LF" is too tight or too loose, please consult your purchasing dealer for maintenance or conduct self-maintenance (cleaning/greasing) of the "Selector Ring LF" in referring to separate "Maintenance of Selector Ring LF Unit". The "2 Click Fixing Ring LF" may need to be replaced if the part has been worn.

Storage

Make sure to remove all batteries, then store in shaded and well-ventilated area within temperature range of [0°C ~ 30°C/32°F ~ 86°F].

Avoid storing near chemicals, high ozone, large temperature and humidity fluctuations (even in the temperature range described above) and magnetic fields (TV sets etc.) to prevent the product from possible malfunction and flooding.

Handling precautions:

- **DO NOT** disassemble the "LF1100h-EWf Light Head Body" to avoid malfunction/flooding.
- Protect from impact shock and vibration, such as vibrating boat deck to avoid accidental damage not only on this product but also on batteries.
- Prevent sands or foreign substances from entering between the 3xAA Battery Box LF and the switch, "Selector Ring LF" and "2 Click Fixing Ring LF" to avoid malfunction/flooding/unstable operation etc.
- **DO NOT** leave the product to extreme heat, such as inside of a sun-heated car or in front of a heater, or in hot direct sunlight, such as a beach or boat deck to avoid malfunction/flooding etc.
- Always hold the "3xAA Battery Box LF" instead holding the protector/filter/Light Shade or "LF1100h-EWf Light Head Body" only to prevent accidental separation of the Protector/Filter leading to drop of this product or loosening of the "LF1100h-EWf Light Head Body" leading to flooding.
- **FULL mode is not usable on land except function check for short period of time(※).** Even for a short period of time to check FULL mode function or using LOW mode on land, be sure to use heat-safe gloves etc. The "LF1100h-EWf Light Head" surface and "3xAA Battery Box LF" surface could have heat more than 50°C/122°F causing personal injury like burn/low temperature burn.
 - ※The function check of FULL mode on land can be conducted only when outer surface of the LF1100h-EWf is below air temperature and **test time should be limited within 5 minutes**. If you need to do consecutive function check, make sure to cool down the unit until its surface gets below air temperature. Working/storage temperature of this product is 0 ~ 30°C/32 ~ 86°F.
- Follow any other handling instructions/precautions explained in separate paper **Safety precautions**.
- When turns OFF this product, **always lock the switch at OFF position**. **Unload all batteries** when not in use including during transportation to avoid accidental malfunction/fire/personal injury resulting from unexpected activation of this product by vibration etc.

Battery

- As batteries have been used, battery voltage gradually decreases making the LF1100h-EWf intensity gets dark little by little. The rated continuous operable time is the duration to get half brightness comparing to initial performance.
- In general, battery performance will decrease as temperature lowers, voltage will recover when not in use and batteries will slowly discharge over time when not used. And, usable time can greatly vary depending on water temperature and how the batteries are used etc. **We recommend replacing with sufficiently charged batteries even before they have been fully drained or carrying spare LF1100h-EWf to avoid battery run out in the middle of a dive especially for night dive.**
- Some NiMH batteries have high self-discharge rates and will begin to decrease their performance (intensity/continuous operable time etc.) immediately after charging. So we recommend using those NiMH batteries within one day after charging.
- Also battery performance will decrease gradually with repeated charging and discharging, even within the possible number of charge-discharge cycles stated on the product package. When you observe less intensity/continuous operable time even with fully-charged (or refreshed) batteries, we recommend to change all batteries.
- Together with these guidelines, be sure to read and understand **Safety Precautions** and any instructions that come with your batteries(rechargeable batteries/battery charger) and comply with any battery manufacturer requirements to ensure proper operation.

Options

- **Single Light Holder LF**
Optional product to attach single INON LF series LED flashlight including this product on “[YS Adapter] compatible arm”. Especially for handy and compact camera system set-up with INON [Shoe Base II] or [Grip Base D4].
- **Strobe Light Holder LF**
Optional product to attach one or two INON LF series LED flashlight on compatible lighting arm together with INON [S-2000], [D-200], [Z-330] etc.
This product is attached on “[YS Adapter] compatible arm” including [Shoe Base II]/[Grip Base D4] etc. through [Z Joint]. Combination with the [Z Adapter II]/[Z Adapter] enables to attach on INON “Arm II System” or “Float Arm System” with [Clamp III].
- **Single Light Holder LF for Tripod**
Optional product to attach one INON LF series LED flashlight on a tripod with 1/4-20UNC standard tripod screw hole. Usable for off camera lighting applications like backlighting or fish-lamp etc.
- **Z Joint**
Optional product to attach [Strobe Light Holder LF] on “[YS Adapter] compatible arm”.
- **Z Adapter II**
Optional product to attach [Strobe Light Holder LF] on INON “Arm II System” or “Float Arm System” with [Clamp III].
The ball-joint is made from metal to firmly fix strobe position by lightly clamp the [Clamp III].
- **Spare O-ring Set (LF)**
Set of two yellow oil-bearing O-rings.
Refer to **[Measures to Prevent Accidental Flooding]** for detail.
- **INON Grease**
③ in the product image.
- **Dome Red Filter LF-EW**
- **Light Shade LF-EW**
④, ⑤ in the product image. Please refer to respective user manuals for detail.
- **Selector Ring LF**
- **2 Click Fixing Ring LF (incl. fixing screws)**
⑥, ⑦ in the product image. Please refer to separate manual **[Maintenance of Selector Ring LF Unit]**.
- **LF1100h-EWf Light Head**
- **LF1300-EWf Light Head**
Optional Light Head which produces same underwater coverage as this product delivering 100 degree with shutter-linked AUTO OFF function at maximum 1300lm/5000K light. This Light Head is interchangeable with the original [LF1100h-EWf Light Head].
- **LF1000-S Light Head**
Optional Light Head which produces 1000 lumen/5000K with 30 degree coverage. This Light Head is interchangeable with the original [LF1100h-EWf Light Head] for other application.
- **LF650h-N Light Head**
Optional Light Head for INON LF series [LF650h-N] which produces 650lm/6500K with super narrow 5 degree coverage designed for dual use on land/underwater. This Light Head is interchangeable with the original [LF1100h-EWf Light Head] for other application.
- **LF800-N Light Head**
Optional Light Head for INON LF series [LF800-N] which produces powerful 800 lumen/5000K with super narrow 5 degree coverage designed for dual use on land/underwater. This Light Head is interchangeable with the original [LF1100h-EWf Light Head] for other application.
- **3xAA Battery Cartridge LF**



Terminals/Contacts: Maintenance


With the increased capacity, improved performance, and longer lifespan of different types of rechargeable batteries, it is possible for the performance of the LF1100h-EWf to become unstable (the LF1100h-EWf doesn't turn ON or flickers) due to bad contacts, caused by dirt or oxidation of the terminal surface of the rechargeable battery itself in addition to ["LF1100h-EWf Light Head" terminal/contact] / ["3xAA Battery Cartridge LF" terminal/contact] / ["3xAA Battery Box LF" terminal/contact] .

For rechargeable battery terminals, it is difficult to distinguish through visual inspection of the terminal surface. As some rechargeable batteries can cause the above problems immediately after purchase because the terminal surface has already been oxidized, it is recommended to inspect and conduct maintenance periodically on the rechargeable battery terminals and LF1100h-EWf terminals/contacts, by following the procedures described below.

● **Battery Terminals**

Conduct following maintenance within limitations/precautions described in battery instructions etc. if maintenance is necessary considering terminal conditions/performance of this product.

- 1) Wipe each terminal surface with a dry soft cloth/clean cotton swab (or similar) to remove any oil or similar residue.
- 2) If above step does not fully clean the terminal, dap a small amount of 『silver polish』 on a cotton swab (or similar) and wipe terminal surface until fully clean. Then clean off any 『silver polish』 residue with a clean swab.



● **"3xAA Battery Cartridge LF" Positive(+) Terminal**


● **"3xAA Battery Cartridge LF" Contacts**

● **"LF1100h-EWf Light Head" Terminal/Contacts**

● **"3xAA Battery Box LF" Contacts**


Clean up surface of contacts/terminals with clean cotton swab to wipe off any dirt/residual oil considering contacts/ terminals condition/performance of this product.

"3xAA Battery Box LF" contact has gold coating so maintenance should not be necessary under normal circumstances. If you observe foreign substances or water droplet etc. clean the contact with clean cotton swab as in the right image



If above step fails to recover expected performance, conduct following maintenance on terminals (4 points) of the "LF1100h-EWf Light Head".

- Dap a small amount of 『silver polish』 on a cotton swab (or similar) and wipe terminal surfaces until fully clean. Then clean off any 『silver polish』 residue with a clean swab.
- Slowly bend up all terminals by a bamboo stick etc. as shown in below images.



● **"Switch" Contact (Not mandatory)**

Maintenance of the switch contact may be necessary only for high frequent users when significant blinking is observed during switch operation. In this case contact your purchasing dealer for servicing.

INON Waterproof LED Light LF1100h-EWf Specifications (*1)

LED	High-intensity Power LED (Cree XM-L2" T6")
Max. Luminous flux (*2)(*3)	FULL mode: approx. 1,100 lumen ["eneloop pro" battery] LOW mode: approx. 330 lumen ["eneloop pro" battery]
Coverage (underwater)	approx. 100° [without a filter and with packaged Red Filter LF-EW]
Color Temp. (*3)	approx. 6,500K
Shutter Linked AUTO-OFF	ON/OFF : Automatically shut off and back on after 0.2 seconds. (Another strobe light detection during AUTO-OFF will add extra 0.2 seconds shut OFF time)
Operable Duration [air] (*4)(*6)	approx. 160 minutes ["eneloop" battery at LOW]
	approx. 210 minutes ["eneloop pro" battery at LOW]
	approx. 90 minutes [Alkaline battery at LOW]
Operable Duration [Underwater] (*5)(*6)	approx. 35 minutes ["eneloop" battery at FULL]
	approx. 165 minutes ["eneloop" battery at LOW]
	approx. 45 minutes ["eneloop pro" battery at FULL]
	approx. 220 minutes ["eneloop pro" battery at LOW]
	approx. 20 minutes [Alkaline battery at FULL]
	approx. 85 minutes [Alkaline battery at LOW]

Compatible Battery	AA "eneloop" / "eneloop pro" battery x 3 (*7)
	AA NiMH [good quality] x 3 (*8)
	AA Alkaline battery x 3
Depth rating	120m / 394' (*9)
Size	Max. diameter 52.1mm/2.1" x 128.8mm/5.1"
Weight (*10)	Air: 268g/9.5oz, Underwater: approx. 109g/3.8oz
Working/Storage Temperature	0°C ~ 30°C / 32°F ~ 86°F
Usable Circumstance	FULL : Underwater only LOW: Land/underwater
LED life time	approx. 10,000 hours
Material/Finishing	Corrosion resistant aluminum alloy/rigid almite,
	ABS, PC, PMMA etc.
Standard accessory	Dome Red Filter LF-EW, Light Shade LF-EW,
	Hand Strap, INON Grease
EMC standards	EN 55015:2013, EN 61547:2009,
	CRF 47 FCC Part 15 Subpart A and B ,
	ICES-003:2016(Issue 6, Amendment 1)

*1) Subject to change without prior notice

*2) Nominal value calculated from LED manufacture specification sheet.

*3) Due to individual variability of LED, drive circuit or battery etc., luminous flux, color temperature or intensity may vary within rated specification.

*4) Average time to get half brightness when continuously turn ON the product with below listed batteries on land (approx. 20°C/68°F).

- "eneloop" battery : Panasonic "eneloop", BK-3MCC, 1.2V, Min. 1,900mAh
- "eneloop pro" battery : Panasonic "eneloop pro", BK-3HCD, 1.2V, Min. 2,500mAh
- Alkaline battery : Panasonic "EVOLTA NEO" LR6NJ, 1.5V

*5) Average time to get half brightness when continuously turn ON the product with below listed batteries underwater (approx. 25°C/77°F).

- "eneloop" battery : Panasonic "eneloop", BK-3MCC, 1.2V, Min. 1,900mAh
- "eneloop pro" battery : Panasonic "eneloop pro", BK-3HCD, 1.2V, Min. 2,500mAh
- Alkaline battery : Panasonic "EVOLTA NEO" LR6NJ, 1.5V

*6) Actual measured data by INON. The value may vary depending on product individual variability, battery manufacture/model, test condition.


*7) "New generation" NiMH batteries carrying less self-discharging and heat generating characteristic comparing to "conventional" or "high-capacity" NiMH including below listed batteries in right confirmed compatible by INON INC. as same as recommended [Panasonic "eneloop"/"eneloop pro" battery (BK-3MCC, BK-3HCD)] .

- Panasonic Corporation Model name: eneloop [recommended] / Model code: BK-3MCC
- Panasonic Corporation Model name: eneloop pro [recommended] / Model code: BK-3HCD
- SANYO Electric Co., Ltd Model name: eneloop [recommended] / Model code: HR-3UTG/HR-3UTGA/HR-3UTGB
- SANYO Electric Co., Ltd Model name: eneloop pro [recommended] / Model code: HR-3UWX
- Sony Corp. Model name: Cycle Energy Blue/Model code : NH-AA-2BKA, NH-AA-4BKA
- Panasonic Corporation Model name: Rechargeable NiMH (AA)/Model code : HHR-3MPS
- Maha Energy Corporation Model name: IMEDION/Model code : MHRAA4
- GP Batteries International Ltd Model name: ReCyko+ /Model code : 210AAHCBE
- ANSMANN AG Model name: maxE/Model code : 5030991, 5030992, 5035052
- Electrochem Automation Inc. Model name: NEXcell energy ON/Model code : n/a (AA 2000mAh)

*8) Some "conventional" or "high-capacity" NiMH rechargeable batteries have significant self-discharge and heat-generating characteristic resulting difficulty to keep their performance during usage. We recommend using recommended batteries.

*9) Without operating the "Switch". INON has confirmed depth rating 70m/230' including switch operation.

*10) Including 3 x AA "eneloop" batteries.



FCC Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Information to user

The user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ICES-003 Notice

This Class B digital apparatus complies with Canadian ICES-003.

Avis NMB-003

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Bundled accessory Light Shade LF-EW is developed based on Mr. Masakazu Akagi's idea.

INON INC. 2-18-9 Dai, Kamakura, Kanagawa, 247-0061 Japan
E-mail support@inon.co.jp Fax: +81(0)467-48-2178
URL http://www.inon.jp/ As of May 2019

Maintenance of Selector Ring LF Unit


It is required to conduct maintenance of the "Selector Ring LF" following below procedures if the ring becomes too tight/loose.

- Step① Remove "Selector Ring LF Unit" to separate "Selector Ring LF" and "Fixing Ring LF".
 Step② Clean, grease the "Selector Ring LF" and "Fixing Ring LF". Replace the "Fixing Ring LF" as necessary.
 Step③ Reassemble "Selector Ring LF" and "Fixing Ring LF" then attach on the "Light Head Body".

Please **DO NOT** conduct this maintenance unless you have fully confidence on this maintenance properly as per instructed in this manual. Otherwise, please contact your purchasing dealer. ***INON INC. assumes NO WARRANTY/LIABILITY for any damage caused by this maintenance.***

Step① Unscrew 4 x fixing screws on the "Selector Ring LF Unit" little by little following order shown in the below top-left image to remove the ring. Then separate "Selector Ring LF" and "Fixing Ring LF".


Check a hole (Hole A) located between two stickers on the "Fixing Ring LF" and the screw hole (Screw Hole A) which accepts a screw from the 「Hole A」.



Step ② Clean to remove old grease, sands/iron sands from the "Selector Ring LF" and "Fixing Ring LF". Then check the protruded part on the "Fixing Ring LF" if it gets worn.

It may require replacing the "Fixing Ring LF" if the protruded part gets worn as per right image and the "Selector Ring LF" is loose when turning.


Type of "Selector Ring LF Unit"	Necessary part
6 Click Selector Ring LF Unit	6 Click Fixing Ring (incl. fixing screw)
2 Click Selector Ring LF Unit	2 Click Fixing Ring (incl. fixing screw)



Apply small amount of packaged grease (about size of a piece of rice) on the upper half of the "Selector Ring LF" inner surface shown on above right image all around evenly and uniformly.

Step ③ Take reverse procedure of Step ① to assemble the "Selector Ring LF" and "Fixing Ring LF" then screw them on the "Light Head Body".

- Reassemble the "Selector Ring LF" and "Fixing Ring LF" so that the triangle arrow on the "Selector Ring LF" points 「Hole A」 on the "Fixing Ring LF".
- Align "Selector Ring LF Unit" 「Hole A」 and "Light Head Body" 「Screw Hole A」 then fasten them.
 (The 「Screw Hole A」 is located close to small 「△ mark」 on the light emitting surface of the "Light Head Body".
 (Make sure to get the screw in the 「Screw Hole A」 or the product won't work properly.)
- Tighten four screws evenly little by little taking reverse procedure. Stop tightening when you feel first stop. **DO NOT** tighten too tight to prevent deformation of the "Fixing Ring LF" causing tough operation when you turn the "Selector Ring LF".



INON INC.

2-18-9 Dai Kamakura Kanagawa 247-0061 JAPAN
 E-mail support@inon.co.jp / URL <http://www.inon.jp/>
 Fax. 0467-48-2178

As of September 2017